


# FSQ-85EDX Photo/Visual System Chart

## ▼ Standard Accessories

- 6. TKA23200 TSA-120 Camera Angle Adjuster
- 10. TKP37001 Coupling (DT)
- 13. TKP00113 50.8 Sleeve
- 14. TKP00103 Coupling (S)
- 46. TKP00101 31.7 Eyepiece Adapter
- 50. TKA23250 Aux. Ring (FB) n° 50
- 70S. TKP27110S Eyepiece holder (50.8/2")
- 80. TKA37582 Flattener 1.01x

## ▼ Optional Accessories

- 12. TKP86005 Visual Adapter (CCA-250)
- 18. TKA36580 Reducer QE 0.73x
- 18C. TKA82580 Reducer CR 0.73x
- 27. TKA00404 4-Turret eyepiece holder
- 30. TKA35201 CA-35 (SKY90)
- 30P. TKA23201 CA-35 (TSA-102)
- 32. TKA01250 T-Mount DX-S (EOS)
- TKA01254 T-Mount DX-S (Nikon)
- 33. TKA01254 T-Mount DX-WR (EOS)
- TKA01255 T-Mount DX-WR (Nikon)
- 34. DSLR Camera
- 36. TKA00210 TCA-4
- 47. 31.7 Eyepiece
- 48. 50.8 (2") Eyepiece
- 49. TKA00547 Diagonal prism 31.7MC
- 60. TKA37595 Extender ED 1.5x
- 71S. TKA00105 Extension Tube (S)
- 74. TKA00543 Diagonal Mirror (50.8/2")
- 75. TKA00111 Adapter (DM) 31.7



TAKAHASHI